Portable compact disc player



AZ9102 **AZ9141 AZ9211 AZ7902 AZ9142** AZ9001 **AZ9103** AZ9213 AZ9214 AZ9002 AZ9104 **AZ9143 AZ9003 AZ9106** AZ9201 **AZ9218 AZ9111 AZ9202** all versions AZ9011 **AZ9101** AZ9113 **AZ9203**

PRODUCT FAMILY DORIS2 - PB2

Service Manual



TABLE OF CONTENTS

Technical specification	1-1
Connections and controls	1-2
Features	
Accessories	
Safety & Warnings	1-4
Service hints	
Repair positions	2-1
Dismantling CD-door	
CD-drive cleaning & lubrication	
CD-drive lens cleaning	
Handling chip components	
Service tools	
Pin description of ICs	3-13-4
Start-up procedure	
e ee e e F F e e e e e e	

Service Test Program	3-63-7
Blockdiagram	3-8
Circuit diagrams Part1 (signal processing) Part2 (control) Part3 (supply)	4-2
Printed circuit board Componentside viewCopperside view	4-4
Exploded view	
Electrical partslist	6-16-4

© Copyright 2000 Philips Consumer Electronics B.V. Eindhoven, The Netherlands All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Published by PW 0005 Service Audio Printed in The Netherlands Subject to modification

CLASS 1 LASER PRODUCT

@B 3103 785 25010







TECHNICAL SPECIFICATION

General

Dimensions (WxHxD) : 128x28x139mm

Weight without batteries : 220g

Power supply modes

DC-in socket : 2.5-6.0V Primary batteries (2xLR6) : 1.6-3.6V Rechargable batteries (AY3362) : 1.6-3.6V

Battery lifetime

BATTERY TYPE	ESP OFF	ESP ON
Primary batteries	≥14h	≥14h
2 x LR6	(20h typ.)	(17h typ.)
Rechargable batteries	≥7h	≥7h
AY3362 (1200mAh)	(9.5h typ.)	(9.5h typ.)

Battery level detection

DETECTION LEVEL	Primary batteries	Rechargable batteries
Battery empty	1.8V +100/-50mV	1.8V +100/-50mV
Battery weak 1	battery empty level + 0.9V ±100mV	battery empty level + 0.7V ±100mV
Battery weak 2	battery empty level + 0.6V ±100mV	battery empty level + 0.5V ±100mV
Battery weak 3	battery empty level + 0.3V ±100mV	battery empty level + 0.3V ±100mV

Charge section (not on all versions)

Current consumption

OPERATION MODE	DC-IN SUP	PLY (4.5V)	BATT. SUPPLY (2.25V)						
OPERATION WODE	ESP OFF	ESP ON	ESP OFF	ESP ON					
Play-mode	100mA typ.	100mA typ.	120mA typ.	120mA typ.					
Jump-mode	220mA typ.	220mA typ.	300mA typ.	400mA typ.					
Stand-by (excl. recharge)	30m/	A typ.	100μ.	A typ.					

Shock resistance

+X/-X direction : \geq 2.5g +Y/-Y direction : \geq 2.5g +Z/-Z direction : \geq 2.0g

Headphone out (measured with 16Ω load, DBB/ESP off)

Output power (THD=10%)

 $\begin{array}{lll} \mbox{/17 version only} & : 2x6mW \ (+1/-3dB) \\ \mbox{all other versions} & : 2x3mW \ (+1/-3dB) \\ \mbox{Frequency response (1mW)} & : 100Hz-20kHz \ within 6dB \\ \mbox{S/N ratio (unwght)} & : \geq 78dB \ (81dB \ typ.) \\ \mbox{S/N ratio (A-wght)} & : \geq 81dB \ (84dB \ typ.) \\ \mbox{THD+N (1kHz, 1mW)} & : \leq 1\% \ (0.2\% \ typ.) \\ \mbox{Channel crosstalk (1kHz, no load)} & : \leq -24dB \ (-44dB \ typ.) \\ \end{array}$

Channel unbalance (-40dB) : ≤5dB Volume attenuation (1kHz) : ≥60dB

Dynamic Bass Boost DBB

DBB STAGE	Free	Frequency response										
DBB STAGE	63kHz	1kHz	10kHz									
DBB 1	+6dB ±2dB	0dB ±2dB	0dB ±2dB									
DBB 2	+9dB ±2dB	0dB ±2dB	+5dB ±2dB									


Laser

Output power : <5mW (3mW typ.)


Wavelength : 780nm


Measurement setup

Use Audio Signal disc SBC429 4822 397 30184



CONNECTIONS AND CONTROLS





- 1stops CD play, clears a program or switches the player off
 2 DBB.....DIGITAL DYNAMIC BASS BOOST switches the bass enhancement on and off
 3 ► II.....skips and searches CD tracks forwards
 4 ► II....switches the player on, starts or pauses CD play
 5display
 6 ←skips and searches CD tracks backwards
 7 PROGRAMprograms tracks and reviews the program
 8 MODEselects the different playing possibilities:
 SHUFFLE, SHUFFLE REPEAT ALL, REPEAT, REPEAT ALL and 5 € 8 €
- 9 RESUME......stores the last position of a CD track played HOLD.....locks all buttons
 OFF.....switches RESUME and HOLD off

 10 LINE OUT/□....3.5mm headphone socket, socket to connect the player to another analogue audio input of an additional appliance

 11 VOL __....adjusts the volume

 12 OPEN ▶....opens the CD lid
 13 4.5V DCsocket for external power supply
 14typeplate
 15 ESP.....typeplate
 16 ESP....Electronic Skip Protection ensures continuous CD playback regardless of vibrations and shocks

TROUBLESHOOTING (excerpt from the Instruction For Use)

Problem	Possible cause	Solution
No power, playback does not start	Batteries Batteries inserted incorrectly	Insert the batteries correctly
	Batteries are empty	Change the batteries
	Contact pins are dirty	Clean them with a cloth
	Mains adapter Loose connection	Connect the adapter securely
	In-car use Cigarette lighter is not powered when ignition is off	Switch on ignition or insert batteries
nF d /5E indication	CD-RW (CD-R) is not recorded properly	Use FINALIZE on the CD Recorder to complete the recording
no d /5E indication	The CD is badly scratched or dirty	Replace or clean the CD
	CD is not or incorrectly inserted	Insert a CD, label upwards
	The laser lens is steamed up	Wait until the lens has cleared
Hald	HOLD is activated	Deactivate HOLD
indication and/or no reaction to controls	Electrostatic discharge	Disconnect the set from power supply or take out the batteries for a few seconds

Problem	Possible cause	Solution
CD skips tracks	The CD is damaged or dirty	Replace or clean the CD
	RESUME, SHUFFLE OF PROGRAM is active	Switch resume, SHUFFLE or PROGRAM Off
No sound or	PAUSE is activated	Press ►II
bad sound quality	Loose, wrong or dirty connections	Check and clean connections
	Volume is not adjusted	Adjust the volume
	Malfunctions due to vicinity of active mobile phones	Keep the player away from active mobile phones
	Strong magnetic fields near the player	Change the player's position or connections
	In-car use Cassette adapter is inserted incorrectly	Insert the cassette adapter correctly
	Temperature inside the car is too high/low	Let the player adjust to the temperature
	Cigarette lighter socket is dirty	Clean the cigarette lighter socket
	Wrong playback direction of the car cassette player's autoreverse feature	Change the autoreverse direction

FEATURES

FEATURES OF CD-PORTABLE PRODUCT FAMILY "DORIS2 – PB2"	AZ7902	AZ9001	AZ9002	AZ9003	AZ9011	AZ9101	AZ9102	AZ9103	AZ9104	AZ9106	AZ9111	AZ9113	AZ9141	AZ9142	AZ9143	AZ9201	AZ9202	AZ9203	AZ9211	AZ9213	AZ9214	AZ9218
CD-RW COMPATIBILITY	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ELECTRONIC SKIP PROTECTION	_	12s	12s	12s	12s	40s	40s	40s	40s	40s	40s	45s	40s	40s	40s	45s						
ESP DRAM SIZE [Mbit]	-	4	4	4	4	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8	8
HOLD / RESUME FUNCTION	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●	●/●
DBB STAGES	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2
ACOUSTIC FEEDBACK	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
PROGRAM MEMORY	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99	99
RECHARGE NiCd / NiMH	●/●	-/-	●/●	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	●/●	-/-	-/-	-/-	-/-	-/-
CORD REMOTE CONTROL	-	-	_	-	-	-	_	-	-	-	_	_	-	-	_	_	_	-	-	-	•	-
LCD BACKLIGHT	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
LINE / OPT. DIGITAL OUTPUT	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-	-/-

ACCESSORIES

ACCESSORIES FOR CD-POR		AZ7902	AZ9001				AZ9002		AZ9003					A 29011	A 20101	A29102	A 79104	151.67	AZ9106	AZ9111	AZ9113	AZ9141	AZ9142	AZ9143	AZ9201	AZ9202				AZ9203	AZ9211	AZ9213	A 232 14	AZ9218
PRODUCT FAMILY "DORIS2	– PB2"	00/	00/	Z00/	/05	/17	00/	/05	/01	60/	/10	/18	/19	-	, ,	,	٠ (-	/17	/17	7	/17			90/	/11	/13		0	-	,00	
AY3170/00 AC/DC Adaptor	4822 219 10617	Х	Х	Х			Х							x											Х	Х					Х	7	x	T
AY3170/02 AC/DC Adaptor	4822 219 10676								Х						T																	Т	T	Т
AY3170/05 AC/DC Adaptor	4822 219 10672				Х			Х																			Х					Т		Т
AY3170/09 AC/DC Adaptor	4822 219 10679									Х		Х																				\top		
AY3170/10 AC/DC Adaptor	4822 219 10681										Х																			Х				
AY3170/12 AC/DC Adaptor	4822 219 10671				×												×	(Χ						
AY3170/13A AC/DC Adaptor	3140 118 31590																												Χ					
AY3170/17 AC/DC Adaptor	4822 219 10616					Х								7	()	< >	(Х	X	Х	Х	Х	Х	Х								Х	\Box	ХX
AY3266/00 Pouch (Neoprene)	12NC follows														Т																		x)	x
AY3362/00 Rechargable Batt. NiMH	3103 308 84120	Х					Х	Х																		Х	Х	Х	Χ)	x	T
AY3501/00 Car Adaptor Cassette	4822 397 10059	0	0	0	0 0	0	0	0	Х	Х	Х	Х	Х	0 0	0) >	()	(X	0	0	Х	Х	Х	Х	0	0	0	0	0	Х	0	X C	o (ΣХ
AY3545/00 Car DC/DC Converter	4822 219 10033	0	0	0	0 0	0	0	0	Х	Х	Х	Х	Х	0 0	0) >	()	(X	0	0	Х	Х	Х	Х	0	0	0	0	0	Х	0	X C	5 (ΣХ
AY3677/00 Earphone (L-plug)	4822 242 11004	Х	Х	Х	XX		Х	Х	Х	Х	Х	Х	X	X			×	(Х	Х	Х	Х	Χ	Х	Х			Х
AY3677/00S Earphone (straight plug)	4822 242 11021														T																	7	x	T
AY3682/00 Headphone (L-plug)	4822 242 11003					Х								7	()	< >		X	X	X	Х	Х	Χ	Х								Х	\neg	x
AY3767/00 Cord Remote Control	12NC follows																															7	x	
AY3464 HiFi Cord (3.5mm L-plug-cinch)	4822 320 11881	0	0	0	0 0	0	0	0	0	0	0	0	0	0 0	0	0	0	0	0	О	0	0	0	0	0	0	0	0	0	0	0	0 0	5 0	0 0

X...supplied with the set, O...optional available

SAFETY & WARNINGS

(GB) WARNING

All ICs and many other semiconductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wristband with resistance. Keep components and tools at this potential.

(F) ATTENTION

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD). Leur longévite pourrait être considérablement écourtée par le fait qu'aucune précaution nést prise à leur manipulation.

Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfileer le bracelet serti d'une résistance de sécurité.

Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.



(D) WARNUNG

Alle ICs und viele andere Halbleiter sind empfindlich gegenüber elektrostatischen Entladungen (ESD). Unsorgfältige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren.

Sorgen Sie dafür, daß Sie im Reparaturfall über ein Pulsarmband mit Widerstand mit dem Massepotential des Gerätes verbunden sind.

Halten Sie Bauteile und Hilfsmittel ebenfalls auf diesem Potential

NL WAARSCHUWING

Alle IC's en vele andere halfgeleiders zijn gevoelig voor electrostatische ontladingen (ESD).

Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen vermindern. Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.

Houd componenten en hulpmiddelen ook op ditzelfde potentiaal.

(I) AVVERTIMENTO

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD).

La loro longevità potrebbe essere fortemente ridatta in caso di non osservazione della più grande cauzione alla loro manipolazione. Durante le riparationi occorre quindi essere collegato allo stesso potenziale che quello della massa delápparecchio tramite un braccialetto a resistenza.

Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.

(B) AVAILABLE ESD PROTECTION EQUIPMENT:

anti-static table mat large 1200x650x1.25mm small 600x650x1.25mm

anti-static wristband

connection box (3 press stud connections, $1M\Omega$)

extendible cable (2m, $2M\Omega$, to connect wristband to connection box) connecting cable (3m, $2M\Omega$, to connect table mat to connection box) earth cable (1M Ω , to connect any product to mat or to connection box) KIT ESD3 (combining all 6 prior products - small table mat) wristband tester

4822 466 10953 4822 466 10958 4822 395 10223 4822 320 11307

4822 320 11305 4822 320 11306 4822 320 11308

4822 310 10671 4822 344 13999

(GB)

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified be used.

Safety components are marked by the symbol \triangle

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées

Les composants de sécurité sont marqués 🛕





Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Originalzustand des Gerätes darf nicht verändert werden. Für Reparaturen sind Originalersatzteile zu verwenden

Sicherheitsbauteile sind durch das Symbol A markiert.



Veiligheidsbepalingen vereisen, dat het apparaat in zijn oorspronkeliijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast. De Veiligheidsonderdelen zijn aangeduid met het symbool

Le norme di sicurezza estigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambiago identici a quelli specificati. Componenty di sicurezza sono marcati con A



DANGER: Invisible laser radiation when open. AVOID DIRECT EXPOSURE TO BEAM.

S Varning!

Osynlig laserstrålning när apparaten är öppnad och spärren är urkopplad. Betrakta ej strålen.

LASER PRODUCT

CLASS 1

(DK) Advarsel!

Usynlig laserstråling ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsaettelse for stråling.

FIN Varoitus!

Avatussa laitteessa ja suojalukituksen ohitettaessa olet alttiina näkymättömälle laserisäteilylle. Älä katso säteeseen!



After servicing and before returning the set to customer perform a leakage current measurement test from all exposed metal parts to earth ground, to assure no shock hazard exists.


The leakage current must not exceed 0.5mA.



Pour votre sécurite, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

SERVICE HINTS


REPAIR POSITION COPPERSIDE



To get access to the copperside of the printed board assembly proceed as follows:

- 1. Remove the bottom screws (6x)
- 2. Lift the bottom-cabinet
- 3. Supply the unit via external DC-socket
- 4. Take care that the door switch is closed during measurements


REPAIR POSITION COMPONENTSIDE



To get access to the componentside of the printed board assembly proceed as follows:

- 1. Remove the bottom screws (6x)
- 2. Open the CD-door
- 3. Lift the top-cabinet and put it backwards on the table
- 4. Supply the unit via the external DC-socket
- Take care that the door switch is closed during measurements

DISMANTLING THE CD-DOOR



To dismantle the CD-door proceed as follows:

- Disconnect the membrane keyboard (flex-foil connector on copperside of printed board)
- 2. Smoothly bend the bridge of the cabinet downwards as shown in ①. Take care not to touch the lens
- 3. Smoothly pull out the right hinge of the CD-door as shown in ②.
- 4. Lift the CD-door



Remark: Do not use screwdrivers or tools like that.

Sharp edges could damage hinge or cabinet part.


VAM2103/08 – DRIVE CLEANING & LUBRICATION

Lubrication of the CD-drive is only necessary in case of symptom "skipping tracks".

The reason can be dirt which sticks to the grease or the grease is getting aged.

Use an acid-free synthetic grease – i.e. "Tribol 9890-2" or equivalent.

Before greasing the mechanism first remove the old grease from the mechanism. Use a cotton swab dipped in alcohol to clean the mechanism.



Cleaning the mechanism

- 1. Clean the lower and upper sledge guidance plane (optical pick-up).
- 2. Clean the spindle shaft.
- 3. Clean the area between the worm gear, idler wheel and clamping spring.

Lubricating the mechanism

- Put one dot of grease onto the upper sledge guidance plane on each side of the sledge. Move the sledge to the inner and outer position to spread the grease.
 Put one dot of grease onto the lower sledge guidance plane on each side of the sledge. Move the sledge to the inner and outer position to spread the grease.
- 2. Put one dot of grease onto the spindle shaft on both sides of the sledge. Move the sledge to the inner and outer position to spread the grease.
- 3. Put one dot of grease between the worm gear and the clamping spring.


VAM2103/08 - LENS CLEANING

Before touching the lens it is advised to clean the surface of the lens by blowing clean air over it in order to avoid that little particles make scratches on the lens.


Because the material of the lens is synthetic and coated with a special anti-reflectivity layer, cleaning must be done with a non-aggressive cleaning fluid. It is advised to use "KODAK LENS CLEANER CAT 176 71 36", available in normal photo shops.


The actuator is a very precise mechanical component and may not be damaged in order to guarantee its full function. It is advised to clean the lens gently (don't press too hard) with a soft and clean cotton bud moistened with the special lens cleaner.


The direction of cleaning must be in the way as indicated in the picture below.





HANDLING CHIP COMPONENTS











SERVICE TOOLS

Audio signal disc SBC429 4822 397 30184
Playability test disc SBC444 4822 397 30245
Test disc 5 (disc without errors) + Test disc 5A (disc with dropout errors, black spots and fingerprints) SBC426/SBC426A 4822 397 30096

ESD PROTECTION EQUIPMENT

Anti-static table mat large 1200x650x1.25mm	4822 466 10953
small 600x650x1.25mm	4822 466 10958
Anti-static wristband	4822 395 10223
Connection box (3 press stud connections, $1M\Omega$)	4822 320 11307
Extendible cable (2m, $2M\Omega$, to connect wristband to connection box)	4822 320 11305
Connecting cable (3m, $2M\Omega$, to connect table mat to connection box)	4822 320 11306
Earth cable (1M Ω , to connect any product to mat or to connection box)	4822 320 11308
KIT ESD3 (combining all 6 prior products - small table mat)	4822 310 10671
Wristband tester	4822 344 13999

PIN DESCRIPTION OF INTEGRATED CIRCUITS

TDA1300T - HF-PREAMPLIFIER AND LASER SUPPLY CIRCUIT (part of CD-drive VAM2103/08)

Pin	Name	Direction	Description
1	O4	HF-preamp → CD10	output of current amplifier 4
2	O6	HF-preamp → CD10	output of current amplifier 6
3	O3	HF-preamp → CD10	output of current amplifier 3
4	O1	HF-preamp → CD10	output of current amplifier 1
5	O5	HF-preamp → CD10	output of current amplifier 5
6	O2	HF-preamp → CD10	output of current amplifier 2
7	LDON	CD10 → HF-preamp	control pin for switching the laser on/off
8	VDDL	+2.7	laser supply voltage
9	VRFE	HF-preamp →	equalized output voltage of sum signal of amplifiers 14
10	VRF	HF-preamp →	unequalized output
11	HG	GND	control pin for gain switch
12	LS	CD10 → HF-preamp	control pin for double speed switch (switches equalization)
13	С	external connection	external capacitor (bandwidth of ALPC)
14	ADJ	→ HF-preamp	reference input
15	GND	GND	0V supply, substrate connection
16	LO	HF-preamp → laser diode	current output to laser diode
17	MI	monitor diode → HF-preamp	laser monitor diode input
18	VDD	+3	positive supply voltage
19	12	GND	photo detector input 2 (not used)
20	15	diode array → HF-preamp	photo detector input 5 (satellite)
21	l1	diode array → HF-preamp	photo detector input 1 (central)
22	13	diode array → HF-preamp	photo detector input 3 (central)
23	16	diode array → HF-preamp	photo detector input 6 (satellite)
24	14	$diode\;array\toHF\text{-}preamp$	photo detector input 4 (central)

MPC17A50VM - 4-CHANNEL H-BRIDGE SERVODRIVER

Pin	Name	Direction	Description
1	CGND	GND	ground (control part)
2	VLG	+2.7	power supply input (control part)
3	ERR2	CD10 → servo driver	error level input (slide error signal)
4	NI2	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
5	OP2	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
6	ERR1	CD10 → servo driver	error level input (focus error signal)
7	NI1	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
8	OP1	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
9	LIM	\rightarrow servo driver	limit control level signal input
10	VR	ightarrow servo driver	control reference voltage input (VR=VLG/2)
11	CLK	\rightarrow servo driver	clock signal input
12	OP3	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
13	NI3	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
14	ERR3	CD10 → servo driver	error level input (radial error signal)
15	OP4	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
16	NI4	\rightarrow servo driver	filter capacitor connection in ABS amp circuit section
17	ERR4	CD10/ μ P \rightarrow servo driver	error level input (motor speed error signal)
18	PHSW	GND	CH4 mode setup (if PHSW=high, CH4 operates half-bridge)
19	POL	CD10 →	CH4 polarity monitor output
20	CFL4	\rightarrow servo driver	pin for connecting filter for capacitor
21	CFL3	\rightarrow servo driver	pin for connecting filter for capacitor
22	OUT4A	servo driver \rightarrow disc motor	H-bridge output A
23	OUT4B	servo driver \rightarrow disc motor	H-bridge output B
24	VIN34	+A	CH3 and CH4 output stage power supply
25	OUT3B	servo driver \rightarrow track actuator	H-bridge output B
26	PGND34	GND	CH3 and CH4 output stage ground
27	OUT3A	servo driver \rightarrow track actuator	H-bridge output A
28	OUT1A	servo driver → focus actuator	H-bridge output A
29	PGND12	GND	CH1 and CH2 output stage ground
30	OUT1B	servo driver \rightarrow focus actuator	H-bridge output B
31	VIN12	+A	CH1 and CH2 output stage power supply
32	OUT2B	servo driver \rightarrow slide motor	H-bridge output B
33	OUT2A	servo driver \rightarrow slide motor	H-bridge output A
34	CFL1	\rightarrow servo driver	pin for connecting filter for capacitor
35	CFL2	→ servo driver	pin for connecting filter for capacitor
36	VG	VG	power supply input (predriver circuit)

SAA7324 - DECODER, DIGITAL SERVO IC AND D/A-CONVERTER CD10 (low voltage version)

Pin	Name	Direction	Description
1	HFREF	→ CD10	comparator common mode input
2	HFIN	→ CD10	comparator signal input
3	ISLICE	$CD10 \rightarrow$	current feedback from data slicer
4	VSSA1	GND	analog ground 1
5	VDDA1	+2.7	analog supply voltage 1
6	IREF	CD10 →	reference current output pin
7	VRIN	CD10 →	reference voltage for servo ADC's
8	D1	HF-preamp → CD10	unipolar current input (central diode signal input)
9	D2	HF-preamp → CD10	unipolar current input (central diode signal input)
10	D3	HF-preamp → CD10	unipolar current input (central diode signal input)
11	D4	HF-preamp → CD10	unipolar current input (central diode signal input)
12	R1	HF-preamp → CD10	unipolar current input (satellite diode signal input)
13	R2	HF-preamp → CD10	unipolar current input (satellite diode signal input)
14	VSSA2	GND CD40 - X TAI	analog ground 2
15	CROUT	CD10 → X-TAL	crystal/resonator output
16	CRIN VDDA2	X-TAL → CD10	crystal/resonator input
17 18	LN	+2.7 CD10 →	analog supply voltage 2 DAC left channel differential output - negative
19	LP	CD10 → CD10 →	DAC left channel differential output - positive
20	VNEG	→ CD10	DAC negative reference input
21	VPOS	→ CD10	DAC positive reference input
22	RN	CD10 →	DAC right channel differential output - negative
23	RP	CD10 →	DAC right channel differential output - positive
24	SELPLL	+2.7	selects whether internal clock multiplier PLL is used
25	TEST1	GND	test control input 1; this pin should be tied low
26	CL16	CD10 →	16.9344 MHz system clock output
27	DATA	CD10 → NPC	serial data output (3-state)
28	WCLK	$CD10 \rightarrow NPC$	word clock output (3-state)
29	SCLK	$CD10 \rightarrow NPC$	serial bit clock output (3-state)
30	EF	$CD10 \rightarrow$	C2 error flag output (3-state)
31	TEST2	GND	test control input 2; this pin should be tied low
32	KILL	CD10 → HF-preamp	kill output (programmable; open-drain)
33	VSSD1	GND	digital ground 2
34	V2/V3	CD10 → NPC	versatile I/O: input versatile pin 2 or output versatile pin 3 (open-drain)
35	WCLI	$NPC \rightarrow CD10$	word clock input (for data loopback to DAC)
36	SDI	$NPC \rightarrow CD10$	serial data input (for data loopback to DAC)
37	SCLI	$NPC \rightarrow CD10$	serial bit clock input (for data loopback to DAC)
38	RESETn SDA	$\mu P \rightarrow CD10$ $\mu P \leftrightarrow CD10$	power-on reset input (active low)
39 40	SCL	µP → CD10 µP → CD10	microcontroller interface data I/O line (open-drain output) microcontroller interface clock line input
41	RAB	µP → CD10	microcontroller interface Clock line input microcontroller interface R/W and load control line input (4-wire bus mode)
42	SILD	µP → CD10	microcontroller interface R/W and load control line input (4-wire bus mode)
43	STATUS	CD10 →	servo interrupt request line/decoder status register output (open-drain)
44	TEST3	GND	test control input 3; this pin should be tied low
45	RCK	→ CD10	subcode clock input
46	SUB	CD10 →	P-to-W subcode bits output (3-state)
47	SFSY	$CD10 \rightarrow \mu P$	subcode frame sync output (3-state)
48	SBSY	CD10 → NPC	subcode block sync output (3-state)
49	CL11/4	CD10 →	11.2896 MHz or 4.2336 MHz (for microcontroller) clock output
50	VSSD2	GND	digital ground 3
51	DOBM	CD10 →	bi-phase mark output (externally buffered; 3-state)
52	VDDD1P	+2.7	digital supply voltage 2 for periphery
53	CFLG	CD10 →	correction flag output (open-drain)
54	RA	CD10 → servo driver	radial actuator output
55 56	FO	CD10 → servo driver	focus actuator output
56 57	SL	CD10 → servo driver	slide control output
57 58	VDDD2C VSSD3	+2.7 GND	digital supply voltage 3 for core
58 59	MOTO1	CD10 → servo driver	digital ground 4 motor output 1; versatile (3-state)
60	MOTO2	CD10 → servo driver	motor output 2; versatile (3-state)
61	V4	$CD10 \rightarrow$ CD10 \rightarrow HF-EQ switch	versatile output pin 4
62	V5	CD10 → HF-GAIN switch	versatile output pin 5
63	V3 V1	innerswitch → CD10	versatile input pin 1
64	LDON	CD10 → HF-preamp	laser drive on output (open-drain)
		· ·	, ,,


SM5903BF - COMPRESSION-TYPE ANTI-SHOCK MEMORY CONTROLLER NPC

Pin	Name	Direction	Description
1	VDD	+2.7	supply voltage
2	UC1	$NPC \leftrightarrow$	μP interface extension I/O line 1
3	UC2	$NPC \leftrightarrow$	μP interface extension I/O line 2
4	UC3	$NPC \leftrightarrow$	μP interface extension I/O line 3
5	UC4	$NPC \leftrightarrow$	μP interface extension I/O line 4
6	UC5	$NPC \leftrightarrow$	μP interface extension I/O line 5
7	TEST1/DIT	$NPC \to$	digital audio interface output
8	TEST2	+2.7	test pin
9	CLK	$CD10 \rightarrow NPC$	16.9344MHz clock input
10	VSS	GND	ground
11	YSRDATA	$CD10 \rightarrow NPC$	audio serial data input
12	YLRCK	$CD10 \rightarrow NPC$	audio serial L/R clock input
13	YSCK	$CD10 \rightarrow NPC$	audio serial bit clock input
14	ZSCK	$NPC \rightarrow CD10$	audio serial bit clock output
15	ZLRCK	$NPC \rightarrow CD10$	audio serial L/R clock output
16	ZSRDATA	$NPC \rightarrow CD10$	audio serial data output
17	YFLAG	$CD10 \rightarrow NPC$	signal processor IC RAM overflow flag
18	YFCLK	GND	crystal-controlled frame clock input
19	YBLKCK	$CD10 \rightarrow NPC$	subcode block clock signal output
20	RESET	$\mu P \rightarrow NPC$	system reset input (active low)
21	ZSENSE	$NPC \rightarrow \mu P$	μP interface status output
22	VDD2	+3	supply voltage
23	YDMUTE	GND	forced mute input
24	YMLD	$\mu P \rightarrow NPC$	μP interface latch clock input
25	YMDATA	$\mu P \rightarrow NPC$	μP interface serial data input
26	YMCLK	$\mu P \rightarrow NPC$	μP interface shift clock input
27	OE	NPC → DRAM	DRAM OE control output (active low)
28	CAS	NPC → DRAM	DRAM CAS control output (active low)
29	D2	NPC ↔ DRAM	DRAM data input/output 2
30	D3	NPC ↔ DRAM	DRAM data input/output 3
31	D0	NPC ↔ DRAM	DRAM data input/output 0
32	D1	NPC ↔ DRAM	DRAM data input/output 1
33	WE	NPC → DRAM	DRAM WE control output (active low)
34	RAS	NPC → DRAM	DRAM RAS control output (active low)
35	A9	NPC → DRAM	DRAM address output 9
36	A8	NPC → DRAM	DRAM address output 8
37	A7	NPC → DRAM	DRAM address output 7
38	A6	NPC → DRAM	DRAM address output 6
39	A5	NPC → DRAM	DRAM address output 5
40	A4	NPC → DRAM	DRAM address output 4
41	A0	NPC → DRAM	DRAM address output 0
42	A1	NPC → DRAM	DRAM address output 1
43	A2	NPC → DRAM	DRAM address output 2
44	A3	$NPC \rightarrow DRAM$	DRAM address output 3

TA2120FN - Stereo Headphone Amplifier

Pin	Name	Direction	Description
1	DBB NF	→ headphone-amp	NF of DBB amplifier
2	ADD OUT	headphone-amp →	output of ADD amplifier
3	RF IN	→ headphone-amp	terminal for ripple filter circuit
4	PWC	→ headphone-amp	center amplifier on/off switch (open = on)
5	VCC	+A/2.7	positive supply voltage
6	В	headphone-amp → HP-socket	output of power amplifier
7	С	headphone-amp → HP-socket	output of center amplifier
8	Α	headphone-amp → HP-socket	output of power amplifier
9	GND	GND	ground of power amplifier
10	MIX OUT	headphone-amp \rightarrow	output of power amplifier (mixed)
11	ALC IN	ightarrow headphone-amp	input terminal for ALC detector circuit
12	ALC DET	\rightarrow headphone-amp	smoothing for ALC detection (GND = ALC off, open = ALC ON)
13	ATT	\rightarrow headphone-amp	power amplifier gain switch (open/VCC = ATT off, GND = ATT on)
14	IN A	\rightarrow headphone-amp	input of power amplifier
15	IN B	\rightarrow headphone-amp	input of power amplifier
16	GND	GND	ground of input stage in power amplifier
17	BEEP IN	$\mu P \rightarrow headphone-amp$	input terminal for beep sound
18	MUTE TC	\rightarrow headphone-amp	terminal for mute smoothing
19	MUTE SW	CD10/µP → headphone-amp	power mute switch (GND/open = mute off, VCC = mute on)
20	POWER	\rightarrow headphone-amp	power switch (VCC = power on, GND/open = power off)
21	BIAS	headphone-amp \rightarrow	BIAS voltage
22	BIAS IN	\rightarrow headphone-amp	filter terminal for BIAS circuit
23	DBB SW	$\mu P \rightarrow headphone-amp$	DBB on/off switch (open/VCC = DBB on, GND = DBB off)
24	DBB OUT	headphone-amp \rightarrow	Output of DBB amplifier (terminal for filter)

START-UP PROCEDURE - FLOW CHART



SERVICE TEST PROGRAM

1. PRELIMINARY SETUP

- To enter the service test program open the CD-door and hold the buttons "MODE" & "NEXT" depressed while turning POWER ON (i.e. connecting the AC/DC adaptor).
- The display shows the software version of the built-in μP (i.e. "5 - 13"). Versions are counted from "DD" onwards; that means the higher the number the newer the software.
- The program is now in the main menu various tests can be entered by pressing the corresponding buttons (see flow chart on next page or detailed description of available tests below).
- To exit the service test program press the "STOP" button or disconnect the set from the power source.

2. DISPLAY TEST

Purpose: Check functionality of display and display driver.

- To enter the display test start the service test program and press the "NEXT" button.
- The display shows test pattern1. All segments are activated for finding open circuits (see flow chart on next page).
- To jump to the next pattern press the "NEXT" button.
- The display shows test pattern2. All alternate pins (2, 4, ...) are activated for finding short circuits (see flow chart on next page).
 To jump back to test pattern1 press the "NEXT" button, to exit the
- display test and return to the main menu press the "STOP" button.

3. KFY TFST

Purpose: Check operation of keys and cord remote control.

- To enter the key test start the service test program and press the "MODE" button.
- The display shows "- ".
- Hold key depressed and check corresponding key code on the display. Key codes can be found in table1 (see flow chart on next
- To exit the key test and return to the main menu press the "STOP" hutton

4. PLAYBACK TEST WITH ERROR ANALYSIS

Purpose: Analyze errors that occur during playback and search for intermittent failures.

- To enter the playback test start the service test program and press the "DBB" button.
- To start the error analysis press the "PLAY" button. Note that the playback test can only be entered if the CD-door is closed.

 The set will read the TOC and start playback.

As long as the playback is free of errors the display shows track and time information like in normal play-mode. In case of errors corresponding error codes will be displayed. The meaning of these error codes can be found in table2 (see flow chart on next page).

Note: Errors can either be "fatal" or "non fatal". Fatal errors always stop the playback, non fatal errors only cause a short interruption of the music. Fatal errors are displayed as long as the set is connected to the power source, non fatal errors are displayed until a new error occurs or a button is pressed.

• To stop the playback test disconnect the set from the power source.

5. SERVO TEST

Purpose: Check door switch, inner switch of CD-drive, movement of slide and acceleration of discmotor.

- · To enter the servo test start the service test program and press the "PLAY" button.
- The display shows "5 xy".
- "x" indicates state of door switch;
- "y" indicates state of inner switch. $x,y = "\tilde{U}"$ means switch is closed; " t" means switch is open.
- To move slide outside hold the "NEXT" button depressed.
- To move slide inside hold the "PREV" button depressed.
- To accelerate the discmotor clockwise hold the "MODE" button depressed.
- To accelerate the discmotor counter-clockwise hold the "PROG" button depressed.
- To enter the focus test press the "PLAY" button, to exit the servo test and return to the main menu press the "STOP" button.

6. FOCUS TEST

Purpose: Check movement of lens and operation of focus servo in "normal" and "CD-RW compatible" mode.

Since the CD-RW reflects much less light than an ordinary CD-A, the gain of the HF-amplifier stage and the sensitivity of the ADC inside the signal processor "CD10" must be increased.

The gain is switched via the HF-GAIN line (pin62 of CD10), the ADC-sensitivity is switched via software ($\mu P \rightarrow CD10$).

During start-up the correct mode is choosen automatically; in the service test program it can be switched manually in order to allow

individual measurements in both conditions.

- The focus servo loop is switched on and the set starts searching the focus ("focus ramping"). As soon as the focus has been found the focus servo loop is closed and the state of the focus is monitored continuously.
- If the focus is OK the display shows " \mathcal{F} ", else "- \mathcal{F} ".
- The ESP-flag indicates the playback mode.

 ESP-flag off means "normal" playback mode (default setting).

 ESP-flag on means "CD-RW compatible" playback mode.
- To toggle between playback modes press the "DBB" button.
- To move slide outside hold the "NEXT" button depressed.
- To move slide inside hold the "PREV" button depressed.
- To accelerate the discmotor clockwise hold the "MODE" button depressed.
- To accelerate the discmotor counter-clockwise hold the "PROG" button depressed.
- In case the focus is OK the discmotor test can be entered by pressing the "PLAY" button, to exit the focus test and return to the main menu press the "STOP" button.

7. DISCMOTOR TEST

Purpose: Check speed regulation of discmotor.

- The speed regulation is switched on and the discmotor starts rotating. If the speed reaches 75% of the nom. speed the display shows " a", else "-a".
- In parallel also the state of the focus is monitored continuously (display " F" or "-F").
 In case the disc speed is OK and the focus is OK the radial test
- can be entered by pressing the "PLAY" button, to exit the discmotor test and return to the main menu press the "STOP" button.

8. RADIAL TEST

Purpose: Check if radial loop locks and an audio signal is audible at the headphone output.

- The radial servo loop is switched on, mute is released and the audio signal is audible. If the system is on track the display shows ر.", else "- ر
- In parallel also the disc speed (display " d" or "- d") and the state of the focus (display " F" or "-F") are monitored continuously.

 Note: In case of radial errors the audio output is muted and muting is not released automatically when the systems recovers from the error. "- ~" remains on the display.
 To open mute again press the "NEXT" or "PREV" button.

- To jump 10 tracks outside press the "NEXT" button.
- To jump 10 tracks inside press the "PREV" button.
- To exit the radial test and return to the main menu press the "STOP" button, to exit the service test program disconnect the set from the power source.

Important remark:


In radial test mode data to the DRAM is written at 1.2 times the nominal speed, and read from the DRAM at nominal speed. Because writing is done faster than reading the DRAM gets full after

In normal play mode the system would now wait until the DRAM is partly emptied again, jump backwards and resume filling at the last written position. However, in radial test mode the jumps would disturb measurements on the radial servo loop.


Therefore this function has been disabled and filling restarts immediately from the current position of the pick-up unit. As a result "jumps" are audible during playback.


SERVICE TEST PROGRAM - FLOW CHART


3-7





3-8













5-1




MECHANICAL PARTSLIST


401 401 402 402 403	3103 304 68080 3103 307 97920 3103 307 99250 3103 307 99280 3103 304 68060	DOOR-BATTERY-2 (not for translucent versions) DOOR-BATTERY-2-LAC (only for translucent versions) CABINET2-ASSEMBLY (not for translucent versions) CABINET2-ASSEMBLY-LAC (only for translucent versions) LEVER-OPEN-2
404 406 407 408 409	3103 304 68110 3103 307 97940 3103 304 68070 3103 301 06500 3103 307 99270	SLIDER-RESUME-2 SLIDER-OPEN-2-LAC HOLDER-OPEN-2 SPRING-SLIDER-OPEN-2 BOTTOM-ASSEMBLY (only for USA version)
409 411 412 413 414	3103 307 99260 3103 301 06520 3103 301 06510 3103 304 68090 3103 301 45180	BOTTOM-PRI-ASSEMBLY (not for USA version) SPRING-OPEN-LONG-L-2C45 SPRING-OPEN-LONG-R-2C45 BRAKE-2 SPRING-BATTERY-SHORT-2
416 417 418 419 421	9305 022 13208 4822 402 10897 3103 301 45200 3103 301 45190 3103 301 45210	CD-DRIVE VAM2103/08 DAMPER-CD DRIVE SPRING-BATTERY-MINUS-2 SPRING-BATTERY-PLUS-2 SPRING-BATTERY-CHARGE-2
422	4822 462 41819 4822 502 13872 3103 300 41570 3103 300 41580	RUBBER FOOT SCREW 1.4x5 PLASTITE SCREW 1.4x2.5 PLASTITE-CR SCREW 1.7x9 PLASTITE-CR




451	3103 307 99200	DOOR-CD-ASSEMBLY-1C (SILVER)
452	3103 307 97960	BUTTON-SET-PLAY-1C-LAC
453	3103 307 97970	BUTTON-PREV-1C-LAC
454	3103 307 97980	BUTTON-NEXT-1C-LAC



451	3103 307 99220	DOOR-CD-ASSEMBLY-2C40B (TRANSLUCENT BLUE, 40s ESP)
451	3103 307 99230	DOOR-CD-ASSEMBLY-2C40G (TRANSLUCENT GREEN, 40s ESP)
451	12NC follows	DOOR-CD-ASSEMBLY-2C40B (TRANSLUCENT RED, 40s ESP)
451	3103 307 99240	DOOR-CD-ASSEMBLY-2C45 (SILVER, 45s ESP)
451	3140 117 59760	DOOR-CD-ASSEMBLY-2C45G (TRANSLUCENT GREEN, 45s ESP)
452	3103 307 98320	BUTTON-SET-PLAY-2C40SQ-LAC-PRI
453	3103 307 97970	BUTTON-PREV-1C-LAC
454	3103 307 97980	BUTTON-NEXT-1C-LAC



451	3103 307 99210	DOOR-CD-ASSEMBLY-2C12 (SILVER, 12s ESP)
451	3140 117 59750	DOOR-CD-ASSEMBLY-2C12B (TRANSLUCENT BLUE, 12s ESP)
452	3103 307 98210	BUTTON-SET-PLAY-2C12-LAC-PRI
453	3103 307 98010	BUTTON-PREV-2C40-LAC
454	3103 307 98020	BUTTON-NEXT-2C40-LAC



451	12NC follows	DOOR-CD-ASSEMBLY-2J40 (SILVER, 40s ESP)
451	12NC follows	DOOR-CD-ASSEMBLY-2J40B (BLUE, 40s ESP)
451	12NC follows	DOOR-CD-ASSEMBLY-2J40G (GREEN, 40s ESP)
451	12NC follows	DOOR-CD-ASSEMBLY-2J40P (PURPLE, 40s ESP)
451	12NC follows	DOOR-CD-ASSEMBLY-2J45 (SILVER, 45s ESP)
452	3103 307 98040	BUTTON-SET-ALL-2J45-LAC-PRI

ELECTRICAL PARTSLIST

CAPACITORS

LLLO I I I I I I I I I I I I I I I I I I	, OL.	O .						
				2366	4822 124 11947	10µF	20%	16V
					2238 780 15654	220nF	10%	16V
MISCELLANEOUS				2368	4822 124 22652	2,2µF	20%	50V
					4822 126 14305	2,2μ1 100nF	10%	16V
1250 2422 026 05086					4822 126 14305			
1251 2422 086 10946				2370 😉	4622 126 14305	100nF	10%	16V
1350 4822 265 11247		T, HEAI	DPHONE HSJ1537	0.400	1000 100 11005	400 5	400/	4.0)./
1350 4822 265 11565	SOCKE	T, HEA	DPHONE/RC HSJ1637		4822 126 14305	100nF	10%	16V
1401 2422 025 16706	6 CONNE	CTOR,	FLEX-FOIL 22P		4822 126 14305	100nF	10%	16V
					4822 126 14305	100nF	10%	16V
1418 4822 277 21643	SWITCH	H-SLIDE	(HOLD/RESUME)	2403©	4822 126 14083	4,7µF	20%	10V
1430 4822 276 12889			'	2404©	4822 126 14043	1µF	20%	16V
1800 4822 265 11576		*	FLEX-FOIL 18P					
1000 4022 200 11070	0011112	01011,	I LEX I OIL IOI	2405©	5322 126 11578	1nF	10%	63V
CAPACITORS				2800©	4822 126 14247	1,5nF	10%	50V
CAPACITORS					4822 126 14249	560pF	10%	50V
2054 @ 4022 426 4447	4	400/	40\/		4822 126 13883	220pF	5%	50V
2251© 4822 126 14472		10%	10V		4822 126 13883	220pF	5%	50V
2252© 3198 017 41050		20%	10V	2000 ©	4022 120 10000	ZZOPI	0 /0	00 0
2253© 4822 126 14083		20%	10V	2004@	1000 106 10000	220nE	E0/	E0\/
2254© 4822 122 3374°		10%	50V		4822 126 13883	220pF	5%	50V
2255© 5322 126 11579	9 3,3nF	10%	63V		4822 126 13883	220pF	5%	50V
					4822 126 13883	220pF	5%	50V
2256© 5322 126 11583	3 10nF	10%	63V		4822 126 13883	220pF	5%	50V
2257© 4822 126 14472	2 1µF	10%	10V	2808©	4822 124 12107	22µF	20%	4V
2258© 4822 122 3176		5%	50V					
2259© 2238 786 56642		10%	16V	2809©	5322 126 11578	1nF	10%	63V
2260 © 4822 126 14083		20%	10V	2810©	4822 124 12107	22µF	20%	4V
2200 @ 4022 120 14000	σ,,,μι	2070	10 V	2811	4822 124 40998	22µF	20%	6,3V
0004 @ 4000 404 4044	47	000/	4) /	2812©	4822 126 14305	100nF	10%	16V
2261© 4822 124 1211		20%	4V		4822 126 14238	2,2nF	10%	50V
2262© 4822 124 1210		20%	4V	2013@	4022 120 14230	2,2111	10 /0	30 V
2263© 4822 126 1430		10%	16V	2011	4000 400 00764	22nE	E0/	E0\/
2264© 4822 122 3176	5 100pF	5%	50V		4822 122 33761	22pF	5%	50V
2266© 4822 126 14472	2 1µF	10%	10V		4822 126 14494	22nF	10%	25V
					5322 126 11583	10nF	10%	63V
2267© 4822 126 1430	5 100nF	10%	16V		4822 126 14043	1µF	20%	16V
2268© 4822 122 31765		5%	50V	2818©	4822 126 14043	1μF	20%	16V
2269© 4822 126 1388°		5%	50V					
2271© 2238 780 15654		10%	16V	2819©	5322 126 11579	3,3nF	10%	63V
2271 © 2230 700 1303-		10%	16V	2820©	5322 126 11579	3,3nF	10%	63V
2212 4022 120 14303) IUUIIF	10%	100		5322 126 11579	3,3nF	10%	63V
0074 @ 4000 400 4400	400-5	4.007	4.0\/		4822 126 14549	33nF	10%	16V
2274© 4822 126 1430		10%	16V		2238 780 15654	220nF	10%	16V
2275© 4822 126 14043		20%	16V	2023@	2230 700 13034	220111	10 /0	10 V
2277© 4822 126 14043		20%	16V	2024@	4000 406 40044	1 En E	E0/	621/
2299© 5322 126 11578	3 1nF	10%	63V		4822 126 13344	1,5nF	5%	63V
2300 © 5322 126 11578	3 1nF	10%	63V		4822 126 13344	1,5nF	5%	63V
					4822 126 14305	100nF	10%	16V
2301 © 5322 126 11578	3 1nF	10%	63V	2827©	4822 124 12111	47µF	20%	4V
2304© 4822 122 3176		5%	50V	2850©	4822 126 14305	100nF	10%	16V
2305© 4822 122 31765			50V					
2306© 5322 126 11578		10%	63V	2852©	4822 126 14305	100nF	10%	16V
2307 © 5322 126 11578		10%	63V	2853©	4822 122 31765	100pF	5%	50V
2307 © 5322 126 11576) IIIF	10%	037		4822 122 33777	47pF	5%	63V
					4822 126 14549	33nF	10%	16V
2308© 4822 126 1449		10%	25V		4822 124 12107	22µF	20%	4V
2309© 4822 126 14494	4 22nF	10%	25V	2011@	4022 124 12107	ΖΖμι	20 /0	4 V
2310© 4822 126 14472	2 1µF	10%	10V	0070	4000 400 44005	400.5	400/	40)/
2312© 4822 124 1210	7 22µF	20%	4V		4822 126 14305	100nF	10%	16V
2313© 4822 124 12107	7 22µF	20%	4V		4822 122 31765	100pF	5%	50V
	·			2891©	4822 126 14249	560pF	10%	50V
2350© 4822 126 14305	5 100nF	10%	16V	2950©	4822 126 13881	470pF	5%	50V
2351© 4822 126 14043		20%	16V	2951 ©	4822 126 13881	470pF	5%	50V
2352© 4822 126 14043		20%	16V					
				2952©	4822 126 13881	470pF	5%	50V
2353 4822 124 11947		20%	16V		4822 126 14472	1µF	10%	10V
2354 4822 124 11947	7 10µF	20%	16V		4822 126 14472	1μF	10%	10V
					4822 124 40998			
2355© 4822 126 12102		20%	50V	2955		22µF	20%	6,3V
2356© 4822 126 14043	3 1µF	20%	16V	2956 ©	4822 126 14247	1,5nF	10%	50V
2357© 4822 124 12107	7 22µF	20%	4V	_				
2358© 4822 126 13909	680pF	10%	50V	2957©	4822 126 14247	1,5nF	10%	50V
2359© 4822 126 13909		10%	50V		4822 126 14305	100nF	10%	16V
	JP.	0		2959©	4822 126 13881	470pF	5%	50V
2360© 4822 126 1430	5 100nF	10%	16V	2960©	4822 126 13881	470pF	5%	50V
2361 © 4822 126 1430		10%	16V		4822 126 13881	470pF	5%	50V
						- 1	- /-	
2362© 4822 126 14549		10%	16V	2962 @	4822 126 13881	470pF	5%	50V
2363© 4822 126 14549		10%	16V		5322 126 11583	10nF	10%	63V
2364© 5322 126 11583	3 10nF	10%	63V					16V
					4822 126 14305	100nF	10%	
2365 4822 124 40998	3 22µF	20%	6,3V	2965©	5322 126 11579	3,3nF	10%	63V

CA	$D \Lambda$	\sim 1 $^{\circ}$	$r \cap$	DС
CA	r_{H}	OI.	ıv	κc

CAPAC	ITORS					
2967©	4822 126	14305	100nF	10%	16V	
	4822 126		100nF	10%	16V	
	4822 126		100nF	10%	16V	
	4822 126				16V	
	4822 126		100nF	10%		
29/16	4822 126	14305	100nF	10%	16V	
2972©	4822 126	13881	470pF	5%	50V	
RESIST	ORS					
3230©	4822 117	12891	220kΩ	1% 0,	0625W	
3231©	4822 117	13632	$100k\Omega$	1% 0,	0625W	
3232©	4822 051	30154	150k Ω	5% 0.	0625W	
	4822 117		82kΩ	5%	0.6W	
	4822 051		$1M\Omega$		0625W	
3235 ⊚	3198 021	22250	2,2ΜΩ	59/, O	0625W	
	4822 117		$100k\Omega$		0625W	
	4822 051		1MΩ		0625W	
	4822 051		1ΜΩ		0625W	
3239©	4822 051	30105	1ΜΩ	5% 0,	0625W	
	4822 051		$470 k\Omega$,	0625W	
3241©	4822 117	12925	47 k Ω	1% 0,	0625W	
3242©	4822 051	30474	$470 \mathrm{k}\Omega$	5% 0,	0625W	
	4822 051		$470 \mathrm{k}\Omega$	5% 0,	0625W	
3244©	4822 051	30103	$10k\Omega$	5%	0,06W	
3245©	4822 116	30467	10kΩ	5%	NTC	
	4822 051		10kΩ		0,06W	
	4822 051		680kΩ		0625W	
	4822 051		150kΩ		0625W	
3249©						
3249 😉	3198 021	32230	2,2ΜΩ	5% 0,	0625W	
3250©	4822 117	13632	$100 k\Omega$	1% 0,	0625W	
3251©	4822 051	30103	$10 \mathrm{k}\Omega$	5%	0,06W	
3252©	4822 117	13632	$100 \mathrm{k}\Omega$	1% 0,	0625W	
3253©	4822 117	13632	$100 \mathrm{k}\Omega$	1% 0,	0625W	
3254©	4822 051	30474	$470 k\Omega$		0625W	
3255 ⊚	4822 051	30103	10kΩ	5%	0,06W	
	4822 117		100kΩ		0625W	
	4822 051		$2.2k\Omega$		0,06W	
			,			
	4822 051 4822 051		680Ω	5%	,	
3239@	4022 031	30303	56kΩ	3 /0 0,	0625W	
3260©	4822 051	30103	$10k\Omega$	5%	0,06W	
3261©	4822 051	30103	$10k\Omega$	5%	0,06W	
3262©	4822 117	12902	$8,2k\Omega$	1% 0,	0625W	
	4822 051		10kΩ	5%	0,06W	
3264©	3198 021	90030	CHIP JU	JMPER (0603	
3266©	4822 051	30103	10kΩ	5%	0,06W	
	3198 021		2,2ΜΩ		0625W	
	4822 051		560Ω		0.06W	
	4822 051		10kΩ		0,06W	
	4822 051		10kΩ		0,06W	
0070	4000 ::=	4000-	4 - 21 ~			
	4822 117		47kΩ	1% 0,	0625W	
	4822 051		5,6kΩ		0625W	
	4822 051		$10k\Omega$		0,06W	
	4822 117		1Ω	5% 0,	0625W	
3283©	4822 117	12917	1Ω	5% 0,	0625W	
3284©	4822 051	30472	$4,7k\Omega$	5%	0,06W	
3285©	4822 051	30183	18kΩ	5%	0,06W	
	4822 051		330kΩ		0625W	
	4822 051		10kΩ	5%	0,06W	
	2120 108		68kΩ		0625W	
3280 €	4822 117	13632	100kΩ	1% 0	0625W	
	4822 051		22kΩ		0,06W	
	4822 117		100kΩ		0,00VV 0625W	
	4822 051		330kΩ		0625W	
	2120 100		220K22		002377	

RESISTORS

3294©	4822 117	12925	$47 k\Omega$	1%00	1625W	
2206	1000 447	12031	220k Ω 100k Ω	10/0/	160EVV	
			100K22	1% 0,0	J625VV	
	4822 117		$100 k\Omega$	1% 0,0	0625W	
3298©	4822 051	30183	18k Ω	5%	0,06W	
3299©	4822 051	30103	$10k\Omega$	5%	0,06W	
3300©	3103 308	52850	POTME.	TER ALI	PS 2x10	OkΩ CX2
3301©	4822 051	30223	$22k\Omega$		0,06W	
	4822 051				0,06W	
	4822 051		22kΩ	5%	0,06W	
3303 ®	4022 031	30223	22132	370	0,0000	
3304⊜	4822 051	30333	$3,3k\Omega$	50/ O I	1625\ <i>M</i>	
	4822 051			5% 0,0	J625VV	
3308©	4822 051	30681	Ω 086	5%	0,06W	
3309©	4822 051	30681	680Ω	5%	0,06W	
3310©	4822 051	30152	1,5k Ω	5%	0,06W	
3311©	4822 051	30152	1,5k Ω 10k Ω	5%	0,06W	
3312©	4822 051	30103	$10k\Omega$	5%	0.06W	
	4822 051		$10k\Omega$	5%	0,06W	
	4822 117			1% 0 (
	4822 051		22kO	F0/.	0.06\\\	
00100	7022 US I	50223	22kΩ	J /0	0,06W	
2246	1000 054	20400	41.0	E0/	0.06147	
	4822 051		1kΩ	5%	0,06W	
3317©	4822 051	30272		5% 0,0	J625W	
3318©	4822 051	30272	$2,7$ k Ω 10 k Ω	5% 0,0	0625W	
3320©	4822 051	30103	10kΩ	5%	0,06W	
3321©	4822 051	30103		5%	0,06W	
3322©	4822 051	30392	$3,9$ k Ω	5%	0.06W	only for ESP
3322®	4822 051 4822 051 4822 051	30332	3.3kO	5% 0 0		only for NON-ESP
3333 ⊚	4822 051	30302	$3,3$ k Ω $3,9$ k Ω	5%		only for ESP
				5 /0 E0/ 0 /		
	4822 051					only for NON-ESP
3349©	4822 051	30333	33 k Ω	5%	0,06W	
_						
3350©	4822 051	30103	10 k Ω 4,7k Ω	5%	0,06W 0,06W	
3351©	4822 051 4822 051	30472			0,06W	
3352©	4822 051	30103	10k Ω	5%	0,06W	
	4822 117		$2,2\Omega$	5% 0.0	0625W	
	4822 117		2,2Ω	5% 0.0	0625W	
		.00.0	_,	0,00,	002011	
3355@	3198 021	36880	6.80	5% 0 (1625W	not for /17
	3198 021		CHIP JL			
						,
	3198 021			-		not for /17
	3198 021		CHIP JU			only for /17
3357©	3198 021	90030	CHIP JU	IMPER (0603	
3359©	4822 051	30103	$10k\Omega$	5%	0,06W	
3360©	4822 051	30332	$3,3k\Omega$	5% 0,0	0625W	only for ESP
	3198 021		CHIP JU			only for NON-ESP
	4822 051		22kΩ		0,06W	,
	4822 117		100kΩ		0,00VV	
JUJ2 ®	1022 111	10002	1 001/22	. 70 0,0	v v	
3363 ⊚	4822 117	12025	/7k0	10/, 0 /	1625\\\	
	4822 117		47kΩ 47kΩ	170 U,U	0625W	
	4822 117					
	4822 051		100Ω	5%	0,06W	
	4822 051		11/157	5% 0,0	0625W	
3367©	4822 051	30105	$1 M\Omega$	5% 0,0	0625W	
3400©	4822 117	12891	$220k\Omega$	1% 0,0	0625W	
	4822 117		220kΩ 100Ω	1% 0.0	0625W	
	4822 051		100Ω	5%	0,06W	
	4822 051		100Ω	- , -	0,06W	
	4822 051		100 <u>s2</u> 12kΩ		0,00W 0625W	
070 7	-1022 UJ I	00123		-	JJZJ V V	
2405 @	1000 054	20500	5,6kΩ 220kΩ	E0/ 0 /) GOEVA	
	4822 051		5,6KQ	5% 0,0	0625W	
	4822 117			,	0625W	
	4822 051		10Ω		0,06W	
3408©	3198 021	32250	$2,2M\Omega$	5% 0,0	0625W	
3409©	4822 117	12891	220kΩ	1% 0,0	0625W	
				,		
3411©	4822 051	30109	10Ω	5%	0,06W	
	4822 051		1kΩ		0,06W	
	4822 051				0,06W	
	4822 051		1kΩ		0,06W	
J+11 W	7022 US I	30102	1 K22	J /0	0,0000	

3293© 2120 108 93057

68kΩ 1% 0,0625W

RESISTORS			RESISTORS	
3800© 4822 051 30103	10kΩ 5% 0,06W		3952© 4822 051 30682	6,8kΩ 5% 0,0625W
3801© 4822 051 30103	10kΩ 5% 0,06W		3953© 4822 051 30682	6,8kΩ 5% 0,0625W
3802© 4822 051 30103	10kΩ 5% 0,06W		3954© 4822 117 12925	47kΩ 1% 0,0625W
3803© 4822 051 30103	10kΩ 5% 0,06W		3955© 4822 117 12925	47kΩ 1% 0,0625W
3804© 4822 051 30103	10kΩ 5% 0,06W		3957© 4822 051 30392	3,9kΩ 5% 0,06W
3805© 4822 051 30103	10kΩ 5% 0,06W		3958© 4822 051 30103	10kΩ 5% 0,06W
3807© 4822 051 30109	10Ω 5% 0,06W		3959© 4822 051 30562	$5,6k\Omega$ 5% $0,0625W$ only for ESP
3808© 4822 051 30102	$1k\Omega$ 5% 0,06W		3959© 4822 051 30273	$27k\Omega$ 5% 0,0625W only for NON-ESI
3809© 4822 051 30339	33Ω 5% 0,0625W		3961© 4822 051 30392	3,9k Ω 5% 0,06W
3810© 4822 051 30474	470kΩ 5% 0,0625W		3963© 3198 021 31840	180kΩ 5% 0,0625W
3811© 4822 051 30222	2,2kΩ 5% 0,06W		COILS	
3812© 4822 051 30223	22kΩ 5% 0,06W			
3813© 4822 051 30333	33kΩ 5% 0,06W		5250 4822 157 51462	10μH 10% Δ
3814© 4822 051 30562	5,6kΩ 5% 0,0625W		5251© 4822 157 70299	2,2µH
3815© 4822 051 30109	10Ω 5% 0,06W		5400 © 4822 242 10845	CER. RES. 4,23MHz
3816© 4822 051 30222	2.21:0		5800 © 4822 157 11781	FILTER, 100MHz
3817© 4822 051 30222	2,2k Ω 5% 0,06W 2,2k Ω 5% 0,06W		5801© 4822 242 81546	CER. RES. 8,4672MHz
3818© 4822 051 30222	$2,2k\Omega$ 5% 0,06W		5802© 4822 157 11781	FILTER, 100MHz
3819© 4822 051 30222	$2,2k\Omega$ 5% 0,06W		5806© 4822 157 11781	FILTER, 100MHz
3820© 4822 051 30222	$2,2k\Omega$ 5% 0,06W $2,2k\Omega$ 5% 0,06W		5834© 4822 157 11781	FILTER, 100MHz
				I ILILIX, TOUMIIL
3821 © 4822 051 30222	2,2kΩ 5% 0,06W		DIODES	
3822© 3198 021 90030	CHIP JUMPER 0603	only for NON-ESP		
3823© 4822 051 30103	10kΩ 5% 0,06W		6250© 9322 128 70685	SS14
3824© 4822 051 30103	10kΩ 5% 0,06W		6251© 4822 130 83757	BAS216
3825© 4822 051 30103	10kΩ 5% 0,06W		6252© 4822 130 83757	BAS216
0000 @ 4000 054 00400	401.0 50/ 0.00///		6253© 4822 130 83757	BAS216
3826© 4822 051 30103	10kΩ 5% 0,06W		6254© 4822 130 83757	BAS216
3827© 4822 051 30103	10kΩ 5% 0,06W		COFF @ 4000 400 70004	LMOOFD
3829© 3198 021 90030	CHIP JUMPER 0603		6255© 4822 130 70064	LM285D
3830© 3198 021 90030 3831© 3198 021 90030	CHIP JUMPER 0603 CHIP JUMPER 0603		6256© 4822 130 82262 6258© 9322 128 70685	BAT54S SS14
3631 © 3196 021 90030	CHIP JUMPER 0003		6261© 4822 130 83757	
3832© 4822 051 30332	3,3kΩ 5% 0,0625W	anhy for ECD	6262© 4822 130 10654	BAS216 BAT254
3833© 3198 021 90030	CHIP JUMPER 0603	only for ESP	0202 © 4822 130 10034	BA1254
3834© 4822 117 12139	22Ω 5% 0,0625W	•	6265© 4822 130 10654	BAT254
3835© 4822 117 13608	4.7Ω 5% 0.0625W		6350© 4822 130 10794	BZX284-C10
3836© 4822 051 30102	1kΩ 5% 0,06W		6351 © 4822 130 82262	BAT54S
2027 @ 4022 054 20402	41-0 50/ 0.00///		6352© 4822 130 82262	BAT54S
3837© 4822 051 30102	1kΩ 5% 0,06W		TDANICICTORS	
3838© 3198 021 90030 3850© 4822 117 12139	CHIP JUMPER 0603 22Ω 5% 0,0625W		TRANSISTORS	
3851© 3198 021 90030	22Ω 5% 0,0625W CHIP JUMPER 0603		7251© 9340 218 50115	BC857BW
3852© 3198 021 90030	CHIP JUMPER 0603		7251© 9340 216 30115 7252© 4822 130 11549	BSH105 ▲
3832 © 3198 021 90030	CHIF JOINIFER 0003		7253© 5322 130 60123	BC807-40
3853© 3198 021 90030	CHIP JUMPER 0603		7253 © 5322 130 00123 7260 © 9340 217 70115	BC847BW
3854© 3198 021 90030	CHIP JUMPER 0603		7263© 9340 217 70115	BC847BW
3855© 4822 117 12139	22Ω 5% 0,0625W		12000 00-0211 10110	2002
3856© 4822 051 30102	$1k\Omega$ 5% 0,0025W		7264 5322 130 61569	BC868
3870 © 3198 021 90030	CHIP JUMPER 0603		7265© 9340 217 70115	BC847BW
22.00 0100 021 00000	J JOHN EN 0000		7266© 9340 217 70115	BC847BW
3871© 3198 021 90030	CHIP JUMPER 0603		7267© 9340 218 50115	BC857BW
3872© 3198 021 90030	CHIP JUMPER 0603		7301© 9340 217 70115	BC847BW
3873© 3198 021 90030	CHIP JUMPER 0603		111.5 00.021110110	- - · · - · ·
3874© 3198 021 90030	CHIP JUMPER 0603		7302© 9340 217 70115	BC847BW
3875© 3198 021 90030	CHIP JUMPER 0603		7351© 9340 217 70115	BC847BW
			7352© 4822 130 42615	BC817-40
3876© 3198 021 90030	CHIP JUMPER 0603		7353© 9340 217 70115	BC847BW
3877© 3198 021 90030	CHIP JUMPER 0603		7355© 9340 218 50115	BC857BW
3878© 3198 021 90030	CHIP JUMPER 0603			
3879© 3198 021 90030	CHIP JUMPER 0603		7800© 9340 218 50115	BC857BW
3880© 4822 117 12139	22Ω 5% 0,0625W		7890© 9340 218 50115	BC857BW
			7891© 9340 218 50115	BC857BW
3881© 4822 051 30103	$10k\Omega$ 5% 0,06W		7892© 9340 217 70115	BC847BW
3882© 4822 051 30103	$10k\Omega$ 5% 0,06W			
3890© 4822 051 30222	$2,2k\Omega$ 5% $0,06W$		7955© 5322 130 63681	BC857CW
3891© 4822 117 11817	1,2kΩ 1% 0,0625W		7956© 5322 130 63679	BC847CW
3892© 4822 051 30221	220Ω 5% 0,06W		7957© 9340 217 70115	BC847BW
			7959© 5322 130 63681	BC857CW
3893© 4822 051 30223	22kΩ 5% 0,06W		7961© 9340 217 70115	BC847BW
3894© 4822 051 30223	22kΩ 5% 0,06W			
3895© 4822 051 30103	·		7962© 9340 217 70115	BC847BW
3951© 3198 021 90030	CHIP JUMPER 0603			
3890	$\begin{array}{cccc} 2,2k\Omega & 5\% & 0,06W \\ 1,2k\Omega & 1\% & 0,0625W \\ 220\Omega & 5\% & 0,06W \\ \\ 22k\Omega & 5\% & 0,06W \\ 22k\Omega & 5\% & 0,06W \\ 10k\Omega & 5\% & 0,06W \\ \end{array}$		7956 © 5322 130 63679 7957 © 9340 217 70115 7959 © 5322 130 63681 7961 © 9340 217 70115	BC847CW BC847BW BC857CW BC847BW

INTEGRATED CIRCUITS

7262© 7300© 7350©	4822 209 17289 9322 142 72685 9322 142 72685 9322 142 97668 3103 308 84100	74LV14PW TC75W51FU TC75W51FU TA2120FN HEADPHONE AMPLIFIER TMP86CH29LF-AZ9000.2
7850© 7870©	9352 641 80557 9322 142 87671 4822 209 16518 9322 138 26668	SAA7324H/M2B CD10/M2B SM5903BF NPC HYB314400BJ-60 4Mbit DRAM MSM51V17405D-60TS-K 16Mbit DRAM
7951©	4822 209 16085 9322 142 72685 9322 142 72685	MPC17A50VM SERVO DRIVER TC75W51FU TC75W51FU